

GROHE Power&Soul® Cosmopolitan



27 667 000

Hand shower 160

4+ spray patterns: GROHE Rain O², Rain, Bokoma Spray, Jet

27 668 000

with 9.5 l/min. GROHE EcoJoy



27 663 000 / 27 663 LSO

Hand shower 130

4+ spray patterns: GROHE Rain O², Rain, Bokoma Spray, Jet

27 664 000

with 9.5 l/min. GROHE EcoJoy



27 660 000

Hand shower 115

2 spray patterns: GROHE Rain O², Rain

27 661 000

with 9.5 l/min. GROHE EcoJoy



27 741 000

Shower wall holder set with hand shower 130 adjustable wall holder



26 174 000 / 26 174 LSO

Shower wall holder set with hand shower 130 non-adjustable wall holder



27 838 000

Shower wall holder set with hand shower 115 non-adjustable wall holder



27 764 000 / 27 764 LSO

Head shower Cosmopolitan 190

4+ spray patterns: GROHE Rain O², Rain, Bokoma Spray, Jet

27 765 000

with 9.5 l/min. GROHE EcoJoy



GROHE EcoJoy



GROHE DreamSpray®



GROHE StarLight®



GROHE QuickFix® Plus



SpeedClean



One-Click Showering



Inner WaterGuide



TwistFree

Colour options: ● 000 | StarLight Chrome | ○ LSO | Moon White



27 745 000
Shower set
with hand shower 160
rail 900 mm
27 746 000
with 9.5 l/min. GROHE EcoJoy



27 733 000
Shower Set
with hand shower 130
rail 900 mm
27 734 000
with 9.5 l/min. GROHE EcoJoy



27 755 000
Shower Set
with hand shower 115
rail 900 mm



27 743 000
Shower Set
with hand shower 160
rail 600 mm
27 744 000
with 9.5 l/min. GROHE EcoJoy



27 731 000
Shower Set
with hand shower 130
rail 600 mm
27 732 000
with 9.5 l/min. GROHE EcoJoy



27 753 000
Shower Set
with hand shower 115
rail 600 mm