

GROHE Rainshower® Water Colours



27 443 000
Hand shower 150
Chrome/Red
2 spray patterns: Rain, SmartRain
27 443 001
with 9.5 l/min. GROHE EcoJoy



27 444 000
Hand shower 150
Chrome/Orange
2 spray patterns: Rain, SmartRain
27 444 001
with 9.5 l/min. GROHE EcoJoy



27 446 000
Hand shower 150
Chrome/Yellow
2 spray patterns: Rain, SmartRain
27 446 001
with 9.5 l/min. GROHE EcoJoy



27 447 000
Hand shower 150
Chrome/Pink
2 spray patterns: Rain, SmartRain
27 447 001
with 9.5 l/min. GROHE EcoJoy



27 448 000
Hand shower 150
Chrome/Purple
2 spray patterns: Rain, SmartRain
27 448 001
with 9.5 l/min. GROHE EcoJoy



27 449 000
Hand shower 150
Chrome/Blue
2 spray patterns: Rain, SmartRain
27 449 001
with 9.5 l/min. GROHE EcoJoy



GROHE
EcoJoy

GROHE
DreamSpray®

GROHE
StarLight®

SpeedClean

EcoButton

Inner
WaterGuide

TwistFree