

GROHE K7

Bring the appealing style of a professional faucet into your home and discover a new world of power and performance. The K7 collection has been designed with the passionate cook in mind, and created with the help of professional chefs, offering you complete flexibility with a stunning centrepiece faucet. With a number of products in the range we know you'll love their combination of aesthetic excellence with unrivalled functionality.





GROHE K7

Sleek and striking, the K7 range offers a professional-style kitchen faucet in two spout heights, featuring a 360° turnable spring arm for maximum flexibility and a solid metal spray which allows for easy switching between mousseur and spray function. The K7 range also offers a swivel spout and variants with extractable dual spray and side sprays which guarantee the highest performance levels as well as stunning design. The K7 collection offers the ultimate flexibility for kitchens where performance really matters.





32 175 000 / 32 175 DC0
Sink mixer



32 176 000 / 32 176 DC0
Sink mixer
with pull-out spray




32 179 000 / 32 179 DC0
Sink mixer
with side spray



32 950 000 / 32 950 DC0
Professional sink mixer



31 379 000 / 31 379 DC0
Professional sink mixer



NEW

30 309 000
Retro-Fit set
for upgrading any GROHE pull-out kitchen
faucet with FootControl technology



40 535 000 / 40 535 DC0
Cosmopolitan soap dispenser
for liquid soaps
storage bin 0.4 l

Colour options:

● 000 | StarLight Chrome | ● DC0 | SuperSteel



GROHE
SilkMove®



GROHE
StarLight®



Professional
Spray



Pull-Out
Dual Spray



Speed
Clean



Comfort
Height



Swivel
Stop



Easy
Dock



GROHE EASY TOUCH / FOOT CONTROL



LIBERATE YOUR HANDS

Kitchens are hands-on places, where multi-tasking is a must. Why not make life easier for yourself with a GROHE touch-activated faucet? We've developed a choice of two innovative solutions that let you control the flow of water without using your hands, making your kitchen more hygienic, convenient and instinctive to use. GROHE Touch faucets can be activated with a simple touch of the wrist or elbow, while GROHE Foot Control faucets turn the flow of water on and off with just a tap of your foot on the base unit. Leave your hands free and keep your faucet sparkling clean. Change the way you control your kitchen with just a single touch.



Ideal for busy kitchens where there's always something going on, GROHE EasyTouch and Foot Control are hygienic and convenient, and both come without any compromise on style. With GROHE's innovative touch technologies you can spend less time cleaning and more time cooking, baking, kneading, finger-painting...living

GROHE EASYTOUCH





LOVE AT FIRST TOUCH

The kitchen is the heart of your life at home – and let's face it, sometimes life gets messy. With GROHE's innovative Touch faucets sticky fingers won't slow you down and cross-contamination is a thing of the past. Hidden GROHE technology lets you start and stop the flow of water with a single tap of your arm, wrist or the back of your hand, anywhere on the spout. No more greasy fingerprints or struggling to turn a lever with your elbow.

