


GROHE EURODISC COSMOPOLITAN

Proving that intensely practical design can work in balance with attractive, modern styling, Eurodisc Cosmopolitan has been created to be the perfect solution for any kitchen setting. You'll love the variety on offer, making for easy installation and even easier use, while a tapering spout and slightly angled lever add to the sleek effect.





GROHE EURODISC COSMOPOLITAN

Get the balance just right in your kitchen with our Eurodisc Cosmopolitan range. From low to high spouts, pull-out dual spray and extractable mousseur options, Eurodisc Cosmopolitan will let you find harmony between elegant good-looks and practical features.





33 770 002
Sink mixer medium spout
31 206 002
for open water heater



32 257 002
Sink mixer medium spout
with pull-out dual spray
31 121 002
for open water heater



33 312 002
Sink mixer medium spout
pre-window



31 237 002
Sink mixer medium spout
with shut-off valve
31 120 002
for open water heater




32 259 002
Sink mixer high spout
31 242 002
for open water heater



31 122 002
Sink mixer high spout
with pull-out mousseur
32 546 002
for open water heater



33 772 002 + 18 349 L02
Sink mixer wall-mounted
with tray



30 309 000
Retro-Fit set
for upgrading any GROHE pull-out kitchen
faucet with FootControl technology



40 535 000
Cosmopolitan soap dispenser
for liquid soaps storage bin 0.4 l



GROHE
SilkMove®



GROHE
StarLight®



Pull-Out
Dual Spray



Pull-Out
Mousseur



OpenWater
Heater



Stop
Valve



Pre
Window



Comfort
Height



Swivel
Stop



Easy
Dock