

# GROHE Europlus

## Washbasin



XS S M L XL

**33 156 002**

XS-Size  
Basin mixer  
with pop-up waste set



XS S M L XL

**32 612 00E**

S-Size  
Basin mixer  
with pop-up waste set



XS S M L XL

**33 155 002**

S-Size  
Basin mixer  
with pop-up waste set  
and pull out spout

## Bidet



XS S M L XL

**33 241 002**

S-Size  
Bidet mixer  
with pop-up waste set

## Bath & shower



**33 577 002**

Shower mixer



**19 537 002 + 35 501 000**

Shower trim set  
+ separate concealed body



**33 547 002**

Bath/shower mixer  
with shower set



**33 553 002**

Bath/shower mixer



**19 536 002 + 35 501 000**

Bath/shower trim set  
+ separate concealed body



GROHE  
SilkMove®



GROHE  
StarLight®



GROHE  
EcoJoy



GROHE  
QuickFix®



XS-Size



S-Size



XL-Size



XS S M L **XL**

**32 618 002**  
XL-Size  
Basin mixer  
for freestanding basins  
with pop-up waste set



XS S **M** L XL

**20 301 000**  
M-Size  
3-hole basin mixer  
with pop-up waste set

## WC



**38 505 000**  
Skate Air  
Wall plate for dual flush  
use with GROHE concealed WC cisterns

## Thermostats



**34 274 000**  
Grotherm 3000  
Thermostatic shower mixer



**19 467 000 + 35 500 000**  
Grotherm 3000  
Thermostatic shower trim set  
+ separate concealed body




**34 276 000**  
Grotherm 3000  
Thermostatic bath/shower mixer



**19 468 000 + 35 500 000**  
Grotherm 3000  
Thermostatic bath/shower trim set  
+ separate concealed body

## Showers



**27 226 001**  
Euphoria 110  
Shower set  
with hand shower Champagne  
rail 900 mm  
GROHE EasyReach tray  
**27 231 001**  
Shower rail 600 mm