



Silhouet Touchless

Clean hands. Clean lines



damixa

Hello, Touchless

Silhouet Touchless is a revolution in touchless taps. The series has been designed specifically for home use and combines a stylish design with functionality to meet all your needs in the kitchen and bathroom. Water waste is reduced, and you never have to touch the tap with dirty hands, risking spread of viruses and bacteria.





Smarter.
Cleaner.
Easier.

The kitchen is the heart of the home, and the tap plays a central role. With Silhouet Touchless, you get both touchless and classic tap functionality in one stylish solution. If, for example, you have just marinated meat or carved a chicken, simply place your hand near the sensor and you can wash your hands without touching the tap and spreading bacteria to the next user. If you need to fill a pot of water, or want the water to run continuously as you peel potatoes, you can use the handle as you would on a classic tap.



The sensor runs on a small 6V battery, which you can easily change yourself. The sensor will flash when it is time to change the battery.



Silhouet Touchless gives you the advantages of both regular taps and touchless technology.



Article no.: 7406200



Article no.: 7406279




Article no.: 7406261



The stylish design matches the Silhouet shower system perfectly, and comes with the same surface finishes: Chrome, brushed brass or matt black.



You can adjust the temperature by rotating the top.



You can increase or decrease the water flow – or turn the water off completely – by clicking the top up and rotating it.

When design makes sense

You will have seen touchless taps in e.g. airports and institutions. You typically only use these sinks to wash your hands, which means that a single fixed setting of temperature and water flow is enough. With Silhouet Touchless, we have succeeded in combining touchless technology with a user-friendly design, where the functional top can be used to control the flow of water and switch between hot and cold.



The sensor detects motion. When you hold your hands under the tap, it will start. When you remove them, it switches off automatically, so you do not use more water than you need. You can adjust the tap at the top, so you can easily change the temperature and flow depending on whether you need to wash your hands, brush your teeth, shave, or fill a glass with cold water.




Article no.: 7402279



Article no.: 7402279



Article no.: 7402261



Tap into your style

Silhouet Touchless has a timeless, simple and Nordic design that offers a good match for both classic and modern homes. The durable surface is available in a chrome, brushed brass or matt black finish, so you can let your particular choice emphasise your personal style.

The design and finishes naturally match the rest of the Silhouet series.

damixa